








Soft closing sliding Door system Installation Manual
(Concealed & External integration)

Picture					
Accessories	Runner	Damper	ST4*16 Cross head tapping screws	2mm Allen key	4mm Allen key
2 DOORS double soft closing(4 Dampers)	8	4	32	1	1
3 DOORS double soft closing(4 Dampers)	12	4	48	1	1


Wardrobe size





Step 1. Damper Installation and Rail Installation

W=L

W=Cabinet Width L=Rail Length




Step 2. Runner installation




Step 3. Door panel installation and Door gap regulation

For concealed


Before installing,lock the button.




After installing panel,loose the button.



Push the door at the end to position the damper;
adjust the door's horizontal



Adjust the gap by regulating up roller




Lock the damper




For external


Before installing,lock the button.




After installing panel,loose the button.



Push the door at the end to position the damper;
adjust the door's horizontal



Adjust the gap by regulating up roller



Lock the damper

